



Quick Start Guide

Indoor

Your unique camera ID is:

Welcome to Y-cam HomeMonitor™


Combining professional wireless internet cameras and a secure online account, HomeMonitor™ allows you to tap in to your home life from anywhere.

Watch live or see recorded events, from an internet-enabled computer or smartphone, keeps you in touch with what matters most.

HomeMonitor™ is super simple to set up and use, just connect a camera, create an account and you're away.

Never miss another important moment! HomeMonitor™ detects motion and can send alerts to keep you updated, whilst simultaneously recording and storing clips in to your secure online account so you can view or download later.

It's easy, it's versatile, it's seeing your stuff – made simple.




Key features

- See and hear what's happening live
- Custom motion detection settings
- Instant motion alerts by email or push notification
- Motion clips recorded into your online account
- Customisable recording and alert schedules
- Infrared nightvision lets you see-in-the-dark
- Watch from your PC, Mac, smartphone, tablet and even Roku

Your account includes*

- Live view from anywhere
- Free email alert notifications
- Free online secure storage in your own private account
- View multiple HomeMonitor cameras under one account

What's in the box



HomeMonitor
Indoor




Stand/wall/
ceiling mount



3m/10ft power
supply with
UK/US/EU plug
attachments



1m/3ft network
Ethernet cable



1-inch screws
x2



Fluted plastic
wall anchors
x2

Missing something? Contact us at <http://support.homemonitor.me>


* Account features may change occasionally as we improve the service, visit homemonitor.me for up-to-date account features

Installing your HomeMonitor™

Decide how you want to connect your HomeMonitor™ to your network – either with Wi-Fi or plugged in to your router with a network cable.


Use your HomeMonitor™ with Wi-Fi

1




Connect HomeMonitor™ to your router and power with provided power supply and network cable. This is required for Wi-Fi setup

2




Visit <http://monitor.y-cam.com> to register your account. Follow online steps for connecting your HomeMonitor™ to Wi-Fi

3



Mount HomeMonitor™ securely in position when prompted and connect power supply provided


4



Follow online steps to complete your account setup


Using your HomeMonitor™ with network cable

1




Mount HomeMonitor™ securely in position

2




Connect HomeMonitor™ to your router and power. You may need an additional network cable if you wish to position your HomeMonitor™ far away from your router

3



Visit <http://monitor.y-cam.com> to register your account

4



Follow online steps to complete your account setup

Getting the best from your HomeMonitor™

It's important your HomeMonitor™ is configured according to your individual requirements. Once you have completed the set up process it is advisable to test it so you are satisfied it will do what you need.

Questions you may want to consider:



What do I want to see in the field of view?



What kind of scenarios do I want to trigger a motion recording?



When do I want to have a motion recorded?



Do I want an email sent to me when a motion recording is triggered?

When you have considered these questions make sure:

- The HomeMonitor™ is securely positioned facing what you want to see
- The motion detection setup matches your needs
- The schedule for the HomeMonitor™ is set to match your schedule

Motion alert & notification tips

HomeMonitor™ is equipped with a sophisticated motion sensor which detects when motion is happening and can alert you to it by email.

If you want to receive email alerts every time motion is detected, you may want to take in to consideration the following tips so that you achieve the best results and reduce the number of worthless alerts:



Active pets (or children!) may activate the motion recording by accident



Movements near busy doors or windows may set off multiple alarms



Moving cars or headlights may cause unwanted motion recordings



Sunlight and reflections of the light may cause the motion alerts to trigger



The HomeMonitor™ Indoor isn't waterproof, so don't use it outside!



IR lights will reflect when pointed at glass and may create false alerts

How notification alerts work

- If you enable the alert notifications and you will receive an email when the system detects motion.
- Once you receive the email alert you can follow the link to HomeMonitor™ and see whether to take action or not.
- Motion recordings will be saved in your account ready for playback or you can download and keep forever.

Day to day usage

Using HomeMonitor™ on your computer or tablet

- Visit <http://monitor.y-cam.com> and login to see your dashboard

The screenshot shows the HomeMonitor web dashboard. At the top left is the HomeMonitor logo. On the top right, it says "Logged in as: JohnDoe" with a "Logout" button. Below this is a navigation bar with five tabs: "My Home", "Live View", "Video Archive", "User Manager", "Camera Manager", and "Support". The main content area is titled "My cameras" and contains three camera entries: "Camera 1", "Camera 2", and "Camera 3". Each entry has a thumbnail image (labeled A, B, C, D, E) and four control buttons: "Connection", "Motion Recording", "Alert Notification", and "Settings". At the bottom of the dashboard, there is a footer with the text: "HomeMonitor™ alerts, recordings and schedules are based on GMT (Standard Time) Copyright 2012 Y-cam Solutions Ltd. All rights reserved. [Terms & Conditions](#). Ver. 1.3" and the Y-CAM logo on the right.

Dedicated app for your smart TV



Roku™

Search for HomeMonitor channel in the Channel Store on your Roku. Roku channel may not be available in all regions. Visit homonitor.me for more information.

Using HomeMonitor™ on your smartphone or tablet

- Visit <http://monitor.y-cam.com/mobile> and login

A

Click/tap to open camera live view

B

Toggles on/off the camera.
When disconnected the camera
will not detect motion, record
clips or transmit live video

C


Toggles on/off motion recording

D

Toggles on/off motion
alert notifications

E

Motion alarm settings
(Desktop website only)



Dedicated apps for your mobile device

Apple iPhone, iPad & iPod touch



iOS 5.1+ required



Visit App Store from
your iOS device &
search for "Y-cam
HomeMonitor" or scan
QR code.

Android smartphones & tablets





Android 2.3.1+ required



Visit Google Play from
your Android device
& search for "Y-cam
HomeMonitor" or scan
QR code.

Technical information



HomeMonitor™ Indoor

Image device: 640 x 480 1/4" CMOS





Viewing angle: Horizontal: 60°, Vertical: 45°

Infrared: 30 LEDs with range <15 m.


Dimensions (W x H x D): 85 x 85 x 30mm

HomeMonitor™ Indoor is not waterproof

Status LED indications:

-  **Green: (solid)** Online
-  **Green: (blinking)** Sending video
-  **Red: (blinking)** Establishing connection
-  **No light:** No power

Add more cameras



Now you have your HomeMonitor installed, why not try one of the following:

Add more cameras

Use multiple cameras, even at multiple locations, all under one account.

Upgrade to Pro

Get 30 days of online storage for your camera for a small annual fee.

Visit homemonitor.me for more information

Safety information

- Do not try to disassemble
- Keep the power supply dry and avoid contact with liquid
- Small parts may cause a choking hazard, keep away from children
- Only use approved accessories and power supplies
- Do not cover the HomeMonitor™. Infrared Lights produce heat which may create a fire hazard
- Ensure the HomeMonitor™ is properly attached to the supplied stand before final installation and positioning
- Compliance is only assured by using the included power supply

Need further help?

If you have any further questions or need support, please visit <http://support.homemonitor.me> – we're happy to help.

Packaging made from recyclable materials. Product RoHS compliant. All compliance certification and safety requirements have been met by the developer and manufacturer, Y-cam Solutions Ltd



Y-cam Solutions Ltd

Vision House
3 Dee Road
Richmond, Surrey
TW9 2JN
United Kingdom

Tel: +44 (0)20 8334 7373

Y-cam Solutions LLC

4500 140th Avenue North
Suite 101
Clearwater
FL 33762
United States

Tel: +1 727 233 8225

For more information or support on HomeMonitor, visit:
<http://www.homemonitor.me> or contact monitor@y-cam.com

Designed in Britain. Made in China.