

BLUBEATS OWNER MANUAL THE TOWER

BLUBEATS



om blubeats.com blubeats.com blubeats.com com blubeats.com blubeats.c

Please read this guide.

Please take the time to follow the instructions in this owner's guide carefully. It will help you set up and operate your system properly and enjoy its advanced features. Please save this guide for future reference.

1. Overview
2. Specifications
3. Set Up
4. Operation
5. Safety Warnings

Overview

Blubeats Tower provides clear and amazing sound with a stylish modern slim look. Our tower is shaped to provide deep and powerful bass and yet remain portable for music in any environment.

Blubeats Tower is the perfect companion for those seeking great sound and stylish decoration for your desk.


Blubeats Tower speaker comes along with:

- Blubeats speaker
- User manual
- USB cable

Blubeats is proud to offer you the very best in a Bluetooth speaker with a unique design. Take the time to read the information to get accustomed to use your new device and show it off to your friends.

Specifications

- Bluetooth 3.0 or 4.0
- Built with CSR Bluetooth module
- NFC for instant pairing
- 1 high definition speaker
- Up to 10 hours of continuous music
- Built-in mic for handsfree call
- Aux-in for external audio source
- Dimension : 80 x 81 x 131 mm
- Rated Power: 3W±10%
- Driver Unit: 50mm*2 4Ω/3W
- Frequency Response: 120Hz-18kHz
- SNR: ≥75dB (Except charging condition)
- THD: ≤ 0.1% (Output1V@1kHz)
- Receiving Range: ≥10M (No blocking)
- Power Supply: DC 5V
- Charging time: 2-3 hours




1. Back (<) switch to last song played and decrease speaker volume. Press to go back to last song. Press and hold to decrease the volume.

2. Play/Pause (⏮) to play or pause a song while paired with a Bluetooth music device.

3. Forward (>) switch to the next song and increase the volume. Press to go forward. Press and hold to increase the volume.

4. Bluetooth (∞) button:

- Press and hold to disconnect the speaker from last paired device.
- Single press to answer or hang up a call.
- Press and hold (in a call) to transfer the call from the speaker to the phone.
- Double press to redial last number called during standby mode.



5. Aux input - When inserting an aux cable, the speaker will disconnect from Bluetooth mode and enter cable input mode.

6. Move the switch to on or off to power or turn off the speaker. The speaker will connect to last known paired device and will enter search mode if no connection has been made within 10 secs.

7. Micro USB port - insert the micro usb cable to charge the speaker.

8. NFC pairing region - region where one can pair to the speaker with a NFC-ready smartphone or tablet.

Operation

Pairing with the Bluetooth device: When you first pair the speaker to your device via Bluetooth, a blue light and a tone will be heard. When you hear two tones, it signals that the speaker has successfully paired with your Bluetooth device.

- a. Turn on your cell phone's Bluetooth connections and power on the speaker.
- b. Search for the corresponding speaker on your available device for pairing menu. Select the speaker.
- c. A tone to confirm the speaker will be heard.
- d. The phone and speaker will remember this connection for the next time you want to use it and will pair faster at that point.

Using the speaker as a speakerphone: When you have paired the speaker to your mobile phone and receive a call, the speaker will flash a blue light rapidly. Press the (Bluetooth button) on the speaker to answer the call. Pressing the (Bluetooth Button) during a call will end it.

Low Battery: when the speaker's battery runs low, a red light will flash every 10 seconds and you will hear a tone every 30 seconds.

Charging: when charging the speaker, a red light will flash continuously and will be off when fully charged.

NFC Pairing: To pair quickly using NFC, please activate the function from your mobile device. NFC pairing allows your NFC-ready smartphone to pair to the speaker instantaneously without having to search for the speaker on the Bluetooth settings menu. Simply "touch" the phone to the NFC region on the speaker. "Touching" the NFC area with the phone again, after it has been paired, will disconnect the Bluetooth connection.

Bluetooth Disconnection can happen in several ways:

1. Bluetooth mode is off.
2. Phone disconnects the connection.
3. When the speaker and the mobile are out of range from each other.

The speaker will disconnect the pairing session if it is out of range for more than 1 minute.

Pairing with a laptop: Different laptops will have different Bluetooth version. Please make sure your version is compatible with the speaker. You may need to install drivers for your Bluetooth function on your laptop. Pairing works similarly as the mobile method. Search for available devices in the Bluetooth menu of your laptop and select the speaker.

Tips on placing the speaker

When using your Blubeats Tower speaker indoors, the tonal quality can vary depending on where the speaker is placed in a room.

When using your speaker outdoors, you should expect the tonal quality to change as you move farther away from the speaker.

Keep the following guidelines in mind when placing your speaker:

- For optimal sound, the front of the speaker, which has the Blubeats logo, should face the user.
- Do not place the speaker on wet or dirty surfaces.
- Do not place the speaker in small areas that are enclosed on all sides except the front, as this will adversely affect sound quality.
- Place the speaker only on its rubber base. Standing the speaker on any side other than its rubber base can cause damage to the speaker and adversely affect sound quality.

Safety Information

When used in the directed manner, this unit has been designed and manufactured to ensure your personal safety. However, improper use can result in potential electrical shock or fire hazards. Please read all safety and operating instructions carefully before installation and use, and keep these instructions handy for future reference. Take special note of all warnings listed in these instructions and on the unit.

WARNINGS:

- To reduce the risk of fire or electrical shock, do not expose the product to rain or moisture.
- Do not expose this apparatus to dripping or splashing, and do not place objects filled with liquids, such as vases, on or near the apparatus. As with any electronic products, use care not to spill liquids into any part of the system. Liquids can cause a failure and/or a fire hazard.
- Do not place any naked flame sources, such as lighted candles, on or near the apparatus.
- The battery pack shall not be exposed to excessive heat such as sunshine, fire or the like.
- Do not dismantle, open or shred battery pack.
- Do not short-circuit the battery or battery pack. Do not store the battery pack haphazardly in a box or drawer where it may short-circuit by other metal objects.
- Do not subject battery pack to mechanical shock.
- In the event of a battery pack leaking, do not allow the liquid to come in contact with the skin or eyes. If contact has been made, wash the affected area with copious amounts of water and seek medical advice.

Warranty

Your Blubeats Tower speaker is covered by limited warranty.

Warranty Period: Under normal use and conditions, this product has a warranty for a period of 12 months from the date of original purchase. Owner will need to retain a copy of the receipt for any warranty request.

The following situations are not covered by warranty:

- a. Improper use and not following the correct instructions.
- b. Use of wrong or defective equipment with the speaker.
- c. Damaged cause by other than intended usage.
- d. Damaged cause by water, fire, heat.
- e. Opening and disassembling the speaker will void the warranty.

Conclusions

As always, we welcome any feedbacks you may have. Please send any inquiries to info@blubeats.com.