

CONGRATULATIONS!

You are now the proud owner of a ROCCAT® Suora FX! The Suora FX' frameless design channels its philosophy as a raw, performance keyboard for gaming purists. Its stripped back style provides you with a more direct gaming experience that puts you closer in touch with its impressive command power. For those who want their finger on the pulse of their games, there's no better choice.

The Suora FX gives you raw power, unchained!

COMPACT FRAMELESS

No palm rest, no thick border, no thumb keys, and no unnecessary media keys – just high-quality, robust mechanical keys mounted on a durable plate.

ADVANCED ANTI-GHOSTING

The Suora FX comes complete with n-key rollover plus a 1000Hz (1ms) polling rate, ensuring that every key stroke will be registered, time and time again.

SOLID DURABLE

Featuring a robust aluminum housing that provides a consistent gaming platform. Complemented by tough mechanical keys with a 50 million key stroke lifecycle.



QUICK-INSTALLATION GUIDE IMPORTANT DOCUMENT



RAW POWER.
UNCHAINED.

SPECIFICATIONS

PACKAGE CONTAINS


- ROCCAT® Suora FX – RGB Illuminated Frameless Mechanical Gaming Keyboard
- Quick-Installation Guide

SYSTEM REQUIREMENTS

- Windows® 7 32/64 bit
- Windows® 8
- Windows® 10
- USB 1.1 port (or better)
- Internet connection (for driver installation)

TECH SPECS

- N-key rollover
- Polling rate 1000Hz (1ms response time)
- 50 Million keystrokes lifecycle
- Multimedia functions and 6 programmable macro keys
- 43cm × 12.5cm size



© 2017 ROCCAT GmbH. All rights reserved. Any product names mentioned in this manual may be trademarks or registered trademarks and are the property of their respective owners. Information contained herein is subject to change without notice. ROCCAT GmbH shall not be made liable for any errors that appear in this manual. This publication or parts of it may not be reproduced without the express consent of the publisher.

ROCCAT GmbH
Otto von Bahrenpark, Paul-Dessau-Str. 3G, 22761 Hamburg, Germany



PLEASE USE YOUR PRODUCT'S SERIAL NUMBER
(LOCATED ON THE BOTTOM LABEL)
TO CHECK ITS AUTHENTICITY AT:
WWW.ROCCAT.ORG/SUPPORT/AUTHENTICITY-CHECK

WWW.ROCCAT.ORG/SUPPORT

Should you need assistance ...
Our support team is ready to help with any technical questions.
Just send an e-mail to support@roccat.org. Or visit our website at:



Swarm provides next-level ROCCAT® product integration. It works a unified driver suite where you can keep tabs on all of your ROCCAT® devices in one place. Say goodbye to multiple tray icons – with Swarm you have a veritable gaming command HQ for every weapon in your arsenal.



KEY REMAPPING

Ensure your most-used gaming keys are remapped so that you're fully prepared for battle.

SELECTED KEY



PRIMARY FUNCTION:

D

GAME MODE FUNCTION:

D

RE-MAP



SET DEFAULT

GAME MODE BUTTON

Quicklaunch gaming profiles and deactivate the Windows key with the game mode button.

MACRO EXAMPLES

WORLD OF WARCRAFT

M1 DPS MACRO

M2 PET ATTACK MACRO

M3 CHARACTER INFO

M4 CHAT PAGE UP

M5 CRAFTING PANEL

M6 QUESTLOG

DE ANLEITUNG

1. Für einen ergonomischeren Stand klappe die Füße an der Unterseite der Tastatur aus.
2. Verbinde den USB-Stecker der ROCCAT® Suora FX mit einer freien USB-Schnittstelle.
3. Starte deinen Computer neu und stelle eine Verbindung zum Internet her.
4. Rufe www.roccat.org/roccat-swarm auf und lade dir die neuste Swarm Version herunter.
5. Starte die Software Installation und folge den Anweisungen.

DK INSTRUKTIONER

1. Til ergonomisk opstilling klappes fødderne på tastaturets bund ud.
2. Forbind ROCCAT® Suora FX's USB-stik med et ledigt USB-interface.
3. Start computeren op, og forbind den med internettet.
4. Navigér til www.roccat.org/roccat-swarm, og download den nyeste version af Swarm.
5. Start software-installationen, og følg anvisningerne på skærmen.

EN INSTRUCTIONS

1. For a more ergonomic position, fold out the stands on the base of the keyboard.
2. Plug the ROCCAT® Suora FX USB connector into any free USB port.
3. Boot your computer and connect to the internet.
4. Navigate to www.roccat.org/roccat-swarm and download the latest version of Swarm.
5. Start the software installation process and follow the on-screen instructions.

ES INSTRUCCIONES

1. Para un equilibrio más ergonómico, saca las patas que están debajo del teclado.
2. Enchufa el conector USB del ROCCAT® Suora FX a un puerto libre USB.
3. Reinicie el ordenador y conéctese a internet.
4. Acceda a la página www.roccat.org/roccat-swarm y descárguese la última versión swarm.
5. Inicie el proceso de instalación de software y siga las instrucciones de la pantalla.

FI OHJEET

1. Käännä näppäimistön alla olevat jalat ulos ergonomista asentoa varten.
2. Liitä ROCCAT® Suora FX:n USB-pistoke vapaaseen USB-liitäntään.
3. Käynnistä tietokoneesi ja yhdistä internetiin.
4. Siirry osoitteeseen www.roccat.org/roccat-swarm ja lataa Swarm-ohjelmiston uusin versio.
5. Käynnistä ohjelmiston asennusprosessi ja seuraa näyttöruudulla näkyviä ohjeita.

FR INSTRUCTIONS

1. Dépliez les pieds sur la face inférieure du clavier pour une plus grande ergonomie.
2. Reliez la fiche USB de la souris ROCCAT® Suora FX à une prise USB libre.
3. Allumez votre PC et connectez-vous à internet.
4. Allez sur www.roccat.org/roccat-swarm et téléchargez la dernière version de Swarm.
5. Débutez l'installation du programme et suivez les indications.

PL INSTRUKCJA

1. Aby uzyskać pozycję ergonomiczną, rozłóż nóżki po spodniej stronie klawiatury.
2. Podłącz wtyk USB ROCCAT® Suora FX do wolnego złącza USB.
3. Uruchom komputer i połącz się z Internetem.
4. Przejdź do strony www.roccat.org/roccat-swarm i pobierz najnowszą wersję Swarm.
5. Rozpocznij instalację oprogramowania i postępuj zgodnie z instrukcjami na ekranie.

PT INSTRUÇÕES

1. Para uma posição mais ergonómica, desdobre os suportes da base do teclado.
2. Ligue os dois conetores USB do ROCCAT® Suora FX em quaisquer portas USB livres.
3. Ligue o computador e estabeleça ligação à internet.
4. Navegar para www.roccat.org/roccat-swarm e descarregar a versão mais recente do Swarm.
5. Iniciar o processo de instalação do software e seguir as instruções indicadas no ecrã.

RU ИНСТРУКЦИИ

1. Для обеспечения эргономичного положения открой ножки на нижней стороне клавиатуры.
2. Соедини USB-штекер ROCCAT® Suora FX со свободным USB-портом.
3. Включите компьютер и выйдите в Интернет.
4. Зайдите на www.roccat.org/roccat-swarm и загрузите самую новую версию Swarm.
5. Начните процесс установки программного обеспечения и следуйте указаниям на экране.

SE INSTRUKTIONER

1. Fäll ut fötterna under tangentbordet så att det står i en ergonomisk ställning.
2. Sätt ROCCAT® Suora FX USB-kontakt i en ledig USB-port.
3. Boota datorn och koppla upp dig på Internet.
4. Gå till www.roccat.org/roccat-swarm och ladda ned den senaste versionen av Swarm.
5. Starta programvaruinstallationen och följ anvisningarna på bildskärmen.