



Ronin-S Camera Compatibility List (as of May 30, 2018)

The camera and lens combinations listed below can be physically balanced and stabilized on the Ronin-S.
 The Supported Feature column indicates camera features that can be accessed by the gimbal and app.
 Cameras and lenses similar in size and weight may be compatible, but will not be listed until official verification by DJI.
 This list will be updated as more camera and lens setups are tested and verified.

Brand	Model	Supported Feature	Compatible Lenses
Canon	60D	Start/stop recording video Capture photo Pull focus (with supported lenses) ¹ Adjust camera parameters ¹	Full EF-S lens range support for APS-C format cameras EF 8-15mm f/4L USM EF 11-24mm f/4L USM EF 16-35mm f/2.8L III USM EF 16-35mm f/4L IS USM EF 17-40mm f/4L USM EF 24-70mm f/2.8L II USM EF 24-70mm f/4L IS USM EF 24-105mm f/4L IS II USM EF 24-105mm f/3.5-5.6 IS STM EF 35mm f/1.4L II USM EF 50mm f/1.2L USM EF 85mm f/1.2L II USM EF 85mm f/1.4L IS USM EF 85mm f/1.8 USM
	70D		
	77D		
	80D		
	7D Series		
	1D Series		
	5D Series		
	6D Series		
Panasonic	GH5/GH5s	Start/stop recording video Capture photo Pull focus (with supported lenses) Adjust camera parameters ¹	H-E08018GK H-HSA35100GK H-HSA12035GK FSA45200GK H-ES12060GK H-X012GK H-FS12060GK H-H025GK H-X015GK H-HS030GK
	GH4	Start/stop recording video Capture photo	
Nikon	D850	Start/stop recording video Capture photo Pull focus (with supported lenses) ¹ Adjust camera parameters ¹	AF-S NIKKOR 14-24mm f/2.8G ED AF-S NIKKOR 16-35mm f/4G ED VR AF-S Zoom-NIKKOR 17-35mm f/2.8D IF-ED AF-S NIKKOR 18-35mm f/3.5-4.5G ED AF-S NIKKOR 24-70mm f/2.8E ED VR AF-S NIKKOR 24-70mm f/2.8G ED AF Zoom-NIKKOR 24-85mm f/2.8-4D IF AF-S NIKKOR 24-85mm f/3.5-4.5G ED VR AF-S NIKKOR 24-120mm f/4G ED VR AF-S NIKKOR 28-300mm f/3.5-5.6G ED VR AF NIKKOR 14mm f/2.8D ED AF-S NIKKOR 20mm f/1.8G ED AF-S NIKKOR 24mm f/1.4G ED AF-S NIKKOR 24mm f/1.8G ED AF-S NIKKOR 50mm f/1.4G AF-S NIKKOR 85mm f/1.4G AF-S NIKKOR 85mm f/1.8G
	D5		
	D3		
	D300		
	D300S		
	D3S		
	D3X		
	D4		
	D4S		
	D500		
	D5000		
	D5100		
	D5200		
	D5300		
	D5500		
	D600		
	D610		
	D700		
	D7000		
	D7100		
D7200			
D750			
D800			
D810			
D810A			
D90			
Df			

Sony	A7 Series	Start/stop recording video Capture photo	FE 24-105mm F4 G OSS FE 16-35mm F2.8 GM FE 12-24mm F4 G FE 100mm F2.8 STF GM OSS FE 85mm F1.8 Vario-Tessar T* FE 16-35mm F4 ZA OSS FE 24-70mm F2.8 GM Vario-Tessar T* FE 24-70mm F4 ZA OSS FE 28-70mm F3.5-5.6 OSS FE 28mm F2 Distagon T* FE 35mm F1.4 ZA Sonnar T* FE 35mm F2.8 ZA Planar T* FE 50mm F1.4 ZA FE 50mm F1.8 Sonnar® T* FE 55mm F1.8 ZA FE 85mm F1.4 GM FE 90mm F2.8 Macro G OSS
	A9		
	A6000 A6300 A6500		E 18-135mm F3.5-5.6 OSS E 10-18mm F4 OSS Vario-Tessar T* E 16-70mm F4 ZA OSS E PZ 18-105mm F4 G OSS E 18-200mm F3.5-6.3 OSS LE Sonnar® T* E 24mm F1.8 ZA
Hasselblad	X1D	Start/stop recording video ¹ Capture photo ¹	XCD 4/21mm XCD 3.5/120mm XCD 3.2/90mm XCD 3.5/45mm XCD 3.5/30mm

¹ Feature will be implemented through a future firmware update.