


Product Name: ECHO XL  
Product Ref: EC150B/WT/W  
Art number: 405705/06/07



 = 40mins

**TECHLINK , A Division Of Tapehand Ltd.**  
Units 7 and 8 Bat and Ball Enterprise Centre  
Bat and Ball Road  
Sevenoaks  
Kent  
United Kingdom  
TN14 5LJ



**(UK)Free Phone 0800 634 2699**  
**(US)Toll Free (844) 499-1159**




**spares@techlink.uk.com**

**Web**

**www.techlink.uk.com**  
**www.recharge.uk.com**


1

C x4




2


C x4



3 Check glass shelves are the correct way up according to the image below!



4  
C x4




5 

Take extra care not to over tighten any screws as this may cause damage!

H  x4

I  x4

K 




6

G  x16

F  x4


K 



7

A x4


K



8

J x2


K




9

E x4

K



10




11



(B)  x4

(D)  x4

(K) 





13



Pull the drawer runners right out

Make sure the bearing runner is at the front



Place drawer keeping the runners extended then push drawer in