User's Guide Dell P1917S/P1917SWh/P2017H/P2217/ P2217Wh

Model No.: P1917S/P1917SWh/P2017H/P2217/P2217Wh Regulatory model: P1917Sc/P1917Sf/P2017Hc/P2217c/P2217t



Notes, Cautions, and Warnings



NOTE: A NOTE indicates important information that helps you make better use of your computer.

 \wedge **CAUTION**: A CAUTION indicates potential damage to hardware or loss of data if instructions are not followed.

WARNING: A WARNING indicates a potential for property damage, personal injury or death.

Other trademarks and trade names may be used in this document to refer to either the entities claiming the marks and names or their products. Dell Inc. disclaims any proprietary interest in trademarks and trade names other than its own.

2016 - 07 Rev. A02

Information in this document is subject to change without notice. © 2016 Dell Inc. All rights reserved.

Reproduction of these materials in any manner whatsoever without the written permission of Dell Inc. is strictly forbidden.

Trademarks used in this text: Dell and the DELL logo are trademarks of Dell Inc.; Microsoft and Windows are either trademarks or registered trademarks of Microsoft. Corporation in the United States and/or other countries, Intel is a registered trademark of Intel Corporation in the U.S. and other countries; and ATI is a trademark of Advanced Micro Devices. Inc. ENERGY STAR is a registered trademark of the U.S. Environmental Protection Agency. As an ENERGY STAR partner, Dell Inc. has determined that this product meets the ENERGY STAR guidelines for energy efficiency.

Contents

At	out your monitor	5
	Package contents	. 5
	Product features	7
	Identifying parts and controls	8
	Monitor specifications	12
	Universal serial bus (USB) interface	25
	Plug and play capability	28
	LCD monitor quality and pixel policy	28
	Maintenance guidelines	28
_		
Se	tting up the monitor2	29
Se	Attaching the stand 2	
Se		29
Se	Attaching the stand	29 31
Se	Attaching the stand	29 31 33
Se	Attaching the stand	29 31 33 34
	Attaching the stand	29 31 33 34 35
	Attaching the stand	 29 31 33 34 35 36

	Using the on-screen display (OSD) menu	38
	Setting up your monitor	54
	Using the Tilt, Swivel, and Vertical Extension	55
Tr	oubleshooting	57
	Self-test	57
	Built-in diagnostics	60
	Common problems	61
	Product-specific problems	63
	Universal serial bus (USB) specific problems	64
Ap	opendix	65
	FCC notices (U.S. Only) and other regulatory information	65
	Contacting Dell	65

About your monitor

Package contents

Your monitor ships with the components shown below. Ensure that you have received all the components and Contacting Dell if something is missing.



NOTE: Some items may be optional and may not ship with your monitor. Some features or media may not be available in certain countries.



Stand base
Power cable (varies by country)
VGA cable
DP Cable
USB 3.0 Upstream Cable (Enables the USB Ports on the Monitor)
 Drivers and Documentation media Quick Setup Guide Safety and Regulatory Information

Product features

The **Dell P1917S/P1917SWh/P2017H/P2217/P2217Wh** flat panel display has an active matrix, Thin-Film Transistor (TFT), Liquid Crystal Display (LCD), and LED backlight. The monitor features include:

- **P1917S/P1917SWh**:48.0 cm (19.0 inch) viewable area display (measured diagonally). 1280 x 1024 resolution, plus full-screen support for lower resolutions.
- **P2017H**:49.5 cm (19.5 inch) viewable area display (measured diagonally). 1600 x 900 resolution, plus full-screen support for lower resolutions.
- **P2217/P2217Wh**:55.9 cm (22.0 inch) viewable area display (measured diagonally). 1680 x 1050 resolution, plus full-screen support for lower resolutions.
- Plug and play capability if supported by your system.
- VGA, HDMI and DisplayPort connectivity.
- Equipped with 1 USB upstream port and 2 USB2.0 / 2 USB3.0 downstream ports.
- On-Screen Display (OSD) adjustments for ease of set-up and screen optimization.
- Software and documentation media includes an Information File (INF), Image Color Matching File (ICM), and product documentation.
- Dell Display Manager Software (in the CD shipped with the monitor).
- Security-cable slot.
- Tilt, swivel, height and rotate adjustment capabilities.
- Removable stand and Video Electronics Standards Association (VESA™) 100 mm mounting holes for flexible mounting solutions.
- 0.3 W power consumption when in the sleep mode.
- Optimize eye comfort with a flicker-free screen and ComfortView feature which minimizes blue light emission.

Identifying parts and controls

Front View



Label Description		
	1 Function buttons (For more information, see Operating your monitor)	
	2 Power on/off button (with LED indicator)	

NOTE: For displays with glossy bezels the user should consider the placement of the display as the bezel may cause disturbing reflections from surrounding light and bright surfaces.

Back View



Back View without monitor stand

Back View with monitor stand

Label	Description	Use
1	VESA mounting holes (100 mm x 100 mm - behind attached VESA Cover)	Wall mount monitor using VESA- compatible wall mount kit (100 mm x 100 mm).
2	Regulatory label	Lists the regulatory approvals.
3	Stand release button	Release stand from monitor.
4	4 Security lock slot Secures monitor with seculock(sold separately).	
		Refer to this label if you need to contact Dell for technical support.
NOTE: Please remove t covering the mounting		Attaches the optional Dell Soundbar. NOTE: Please remove the plastic strip covering the mounting slots before affixing the Dell Soundbar.
		Use to organize cables by placing

Side View



Label	Description	Use
1	USB downstream port	Connect your USB device.
		NOTE : To use this port, you must connect the USB cable (shipped with your monitor) to the USB-upstream port on the monitor and to your computer.

Bottom View



Bottom view without monitor stand

Label Description Use		Use	
1	Power port	Connect the power cable.	
2	HDMI port	Connect your computer with HDMI cable(optional).	
3	DP port	Connect your computer to the monitor using a DP cable.	
4	VGA port Connect your computer with VGA cable.		
5	5 USB connector (x2 downstream, x1 upstream) Connect the USB cable that came with your to the computer. Once the cable is connected can use the USB connectors on the rear side bottom side of the monitor.		
6	Stand lock feature	To lock the stand to the monitor using a M3 x 6mm screw (screw not included).	

Monitor specifications

Active matrix - TFT LCD		
In-Plane Switching Technology		
480.00 mm (19.00 in)	494.11 mm (19.45 in)	
374.78 mm (14.76 in)	433.92 mm (17.08 in)	
299.83 mm (11.80 in)	236.34 mm (9.30 in)	
1123.70 cm ² (174.17 in ²)	1025.53 cm ² (158.96 in ²)	
0.293 mm x 0.293 mm	0.271 mm x 0.263 mm	
86	94	
178° (vertical) typical		
178° (horizontal) typical		
250 cd/m² (typical)		
1000: 1 (typical)		
4 Million: 1 (Dynamic)		
5:4	16:9	
Anti-glare with 3H hardness	S	
White LED edgelight system	1	
6 ms (gray to gray - fast mo	ode)	
8 ms (typical - normal mod	e)	
16.7 million colors		
84% (CIE 1976), 72% (CIE 19	931)	
USB 3.0 super-speed hub (with 1x USB 3.0 upstream port, 2x USB 3.0 downstream ports and 2x USB2.0 downstream ports)		
Yes		
1xDP (ver 1.2)		
1xHDMI (ver 1.4)		
1xVGA		
1xUSB3.0 port - Upstream		
2xUSB3.0 port - Side		
2xUSB2.0 port - Bottom		
	480.00 mm (19.00 in) 374.78 mm (14.76 in) 299.83 mm (11.80 in) 1123.70 cm ² (174.17 in ²) 0.293 mm x 0.293 mm 86 178° (vertical) typical 178° (horizontal) typical 250 cd/m ² (typical) 1000: 1 (typical) 4 Million: 1 (Dynamic) 5:4 Anti-glare with 3H hardness White LED edgelight system 6 ms (gray to gray - fast mod 16.7 million colors 84% (CIE 1976), 72% (CIE 1976) USB 3.0 super-speed hub (xport, 2x USB 3.0 downstread downstream ports) Yes 1xDP (ver 1.2) 1xHDMI (ver 1.4) 1xVGA 1xUSB3.0 port - Upstream	

Border width (edge of	16.9mm (Top)	18.1mm (Top)	
monitor to active area)	15.4mm(Left/Right)	13.8mm(Left/Right)	
	17.6mm(Bottom)	18.8mm(Bottom)	
Security	Security lock slot (cable lock sold separately)		
Adjustability	Height adjustable stand (130mm)		
	Tilt (5°/21°)		
	Swivel (45°)		
	Pivot (90°)		

Model	P2217/P2217Wh	
Screen type	Active matrix - TFT LCD	
Panel type	Twisted Nematic	
Viewable image		
Diagonal	558.68 mm (22.00 in)	
Horizontal, Active Area	473.76 mm (18.65 in)	
Vertical, Active Area	296.10 mm (11.66 in)	
Area	1402.80 cm ² (217.43 in ²)	
Pixel pitch	0.282 mm x 0.282 mm	
Pixel per inch (PPI)	90	
Viewing angle (vertical /	160° (vertical) typical	
horizontal)	170° (horizontal) typical	
Brightness	250 cd/m² (typical)	
Contrast ratio	1000: 1 (typical)	
	4 Million: 1 (Dynamic)	
Aspect ratio	16:10	
Display screen coating Anti-glare with 3H hardness		
Backlight White LED edgelight system		
Response time	5 ms (black to white)	
Color depth 16.7 million colors		
Color Support	84% (CIE 1976), 72% (CIE 1931)	
Built-in devices	USB 3.0 super-speed hub (with 1x USB 3.0 upstream port, 2x USB 3.0 downstream ports and 2x USB2.0 downstream ports)	
Dell display manager compatibility	Yes	
Connectivity	1xDP (ver 1.2)	
	1xHDMI (ver 1.4)	
	1xVGA	
	1xUSB3.0 port - Upstream	
	2xUSB3.0 port - Side	
	2xUSB2.0 port - Bottom	

Border width (edge of	16.8mm (Top)
monitor to active area)	14.8mm(Left/Right)
	17.5mm(Bottom)
Security	Security lock slot (cable lock sold separately)
Adjustability	Height adjustable stand (130mm)
	Tilt (5°/21°)
	Swivel (45°)
	Pivot (90°)

Resolution specifications

Model	P1917S/P1917SWh	P2017H	P2217/P2217Wh
Horizontal scan range	30 kHz to 81 kHz (automatic)	30 kHz to 83 kHz (aut	omatic)
Vertical scan range	56 Hz to 76 Hz (automatic)		
Maximum preset resolution	1280 x 1024 at 60 Hz	1600 x 900 at 60 Hz	1680 x 1050 at 60 Hz

Supported video modes

Model	P1917S/P1917SWh/P2017H/P2217/P2217Wh
Video display capabilities (VGA, HDMI & DP playback)	480i, 480p, 576i, 576p, 720p, 1080i, 1080p

Preset display modes

P1917S/P1917SWh

Display Mode	Horizontal Frequency (kHz)	Vertical Frequency (Hz)	Pixel Clock (MHz)	Sync Polarity (Horizontal / Vertical)
VESA, 720 x 400	31.5	70.1	28.3	-/+
VESA, 640 x 480	31.5	60.0	25.2	-/-
VESA, 640 x 480	37.5	75.0	31.5	-/-
VESA, 800 x 600	37.9	60.3	40.0	+/+
VESA, 800 x 600	46.9	75.0	49.5	+/+
VESA, 1024 x 768	48.4	60.0	65.0	-/-
VESA, 1024 x 768	60.0	75.0	78.8	+/+
VESA, 1152 x 864	67.5	75.0	108.0	+/+
VESA, 1280 x 1024	64.0	60.0	108.0	+/+
VESA, 1280 x 1024	80.0	75.0	135.0	+/+

P2017H

Display Mode	Horizontal Frequency (kHz)	Vertical Frequency (Hz)	Pixel Clock (MHz)	Sync Polarity (Horizontal / Vertical)
VESA, 720 x 400	31.5	70.1	28.3	-/+
VESA, 640 x 480	31.5	60.0	25.2	-/-
VESA, 640 x 480	37.5	75.0	31.5	-/-
VESA, 800 x 600	37.9	60.3	40.0	+/+
VESA, 800 x 600	46.9	75.0	49.5	+/+
VESA, 1024 x 768	48.4	60.0	65.0	-/-
VESA, 1024 x 768	60.0	75.0	78.8	+/+
VESA, 1152 x 864	67.5	75.0	108.0	+/+
VESA, 1600 x 900	60.0	60.0	108.0	+/+

P2217/P2217Wh

Display Mode	Horizontal Frequency (kHz)	Vertical Frequency (Hz)	Pixel Clock (MHz)	Sync Polarity (Horizontal / Vertical)
VESA, 720 x 400	31.5	70.1	28.3	-/+
VESA, 640 x 480	31.5	60.0	25.2	-/-
VESA, 640 x 480	37.5	75.0	31.5	-/-
VESA, 800 x 600	37.9	60.3	40.0	+/+
VESA, 800 x 600	46.9	75.0	49.5	+/+
VESA, 1024 x 768	48.4	60.0	65.0	-/-
VESA, 1024 x 768	60.0	75.0	78.8	+/+
VESA, 1152 x 864	67.5	75.0	108.0	+/+
VESA, 1280 x 1024	64.0	60.0	108.0	+/+
VESA, 1280 x 1024	80.0	75.0	135.0	+/+
VESA, 1680 x 1050	65.29	60.0	146.25	-/+

Electrical specifications

Model	P1917S/P1917SWh/P2017H/P2217/P2217Wh
Video input signals	 Analog RGB, 0.7 Volts +/-5%, positive polarity at 75 ohm input impedance
	 HDMI 1.4, 600mV for each differential line,100 ohm input impedance per differential pair
	 DisplayPort 1.2**, 600mV for each differential line, 100 ohm input impedance per differential pair
AC input voltage/frequency/	100 VAC to 240 VAC / 50 Hz or 60 Hz ± 3 Hz /
current	1.5A (typical)
Inrush current	• 120 V: 30 A (Max.) at 0°C (cold start)
	• 240 V: 60 A (Max.) at 0°C (cold start)

Physical characteristics

Model	P1917S/P1917SWh	P2017H	P2217/P2217Wh			
Signal cable type	• Digital: detachable, HDMI, 19 pins.					
	 Digital: detachable, DP, 20 pins. 					
	Analog: detachable	• Analog: detachable, D-Sub, 15 pins				
	Universal Serial Bus	s: USB, 9 pins				
Dimensions (with s	stand)					
Height (extended)	499.3 mm (19.66 in)	468.8 mm (18.46 in)	497.4 mm (19.58 in)			
Height (compressed)	369.3 mm (14.54 in)	338.8 mm (13.34 in)	367.4 mm (14.46 in)			
Width	405.6 mm (15.97 in)	461.5 mm (18.17 in)	503.4 mm (19.82 in)			
Depth	180.0 mm (7.09 in)	180.0 mm (7.09 in)	180.0 mm (7.09 in)			
Dimensions (witho	out stand)		·			
Height	334.3 mm (13.16 in)	273.2 mm (10.76 in)	330.4 mm (13.01 in)			
Width	405.6 mm (15.97 in)	461.5 mm (18.17 in)	503.4 mm (19.82 in)			
Depth	50.3 mm (1.98 in)	50.1 mm (1.97 in)	50.3 mm (1.98 in)			
Stand dimensions						
Height (extended)	400.8 mm (15.78 in)	400.8 mm (15.78 in)	400.8 mm (15.78 in)			
Height (compressed)	354.4 mm (13.95 in)	354.4 mm (13.95 in)	354.4 mm (13.95 in)			
Width	242.6 mm (9.55 in)	242.6 mm (9.55 in)	242.6 mm (9.55 in)			
Depth	180.0 mm (7.09 in)	180.0 mm (7.09 in)	180.0 mm (7.09 in)			
Weight						
Weight with packaging	6.61 kg (14.57 lb)	6.13 kg (13.51 lb)	7.03 kg (15.49 lb)			
Weight with stand assembly and cables	5.13 kg (11.31 lb)	4.73 kg (10.42 lb)	5.33 kg (11.75 lb)			
Weight without stand assembly (no cables)	2.60 kg (5.73 lb)	2.40 kg (5.29 lb)	3.00 kg (6.61 lb)			
Weight of stand assembly	2.10 kg (4.63 lb)	2.10 kg (4.63 lb)	2.10 kg (4.63 lb)			
Front-frame gloss	2 - 4	2 - 4	2 - 4			

Environmental characteristics

Model	P1917S/ P1917SWh	P2017H	P2217/P2217Wh			
Compliant Standards						
Energy Saver feature for	Energy Star certified	d Monitor				
EPEAT Gold registered i	n the U.S. EPEAT reg	istration varies by co	buntry.			
See www.epeat.net for I	registration status by	r country.				
TCO-certified display						
BFR/PVC- Free monitor	(excluding external	cables)				
Energy Gauge shows th	e energy level being	consumed by the m	nonitor in real time			
Temperature						
Operating	0°C to 40°C (32°F t	o 104°F)				
Non-operating	• Storage: -20°C to	o 60°C (-4°F to 140°	F)			
	• Shipping: -20°C to 60°C (-4°F to 140°F)					
Humidity						
Operating	20% to 80% (non-condensing)					
Non-operating	 Storage: 10% to 90% (non-condensing) 					
	 Shipping: 10% to 90% (non-condensing) 					
Altitude						
Operating (maximum)	5,000 m (16,400 ft)					
Non-operating (maximum)	12,192 m (40,000 ft)					
Thormal discipation	• 129.7 BTU/ hour(maximum)	• 133.1 BTU/ hour(maximum)	• 136.6 BTU/ hour(maximum)			
Thermal dissipation	• 47.8 BTU/ hour(typical)	• 44.4 BTU/ hour(typical)	• 51.2 BTU/ hour(typical)			

Power management modes

If you have VESA's DPMTM compliance display card or software installed in your PC, the monitor can automatically reduce its power consumption when not in use. This is referred to as Power Save Mode*. If the computer detects input from the keyboard, mouse or other input devices, the monitor automatically resumes functioning. The following table shows the power consumption and signaling of this automatic power saving feature.

* Zero power consumption in off mode can only be achieved by disconnecting the main cable from the monitor.

P1917S/P1917SWh

VESA Modes	Horizontal Sync	Vertical Sync	Video	Power Indicator	Power Consumption
Normal operation	Active	Active	Active	White	38 W (maximum)** 14 W (typical,without USB load)
Active-off mode	Inactive	Inactive	Blanked	White (Glowing)	Less than 0.3 W
Switch off	-	-	-	Off	Less than 0.3 W
Energy Star			Power Consu	mption	
P _{on}			13.0 W		
E _{tec}			44.3 kWh		

P2017H

VESA Modes	Horizontal Sync	Vertical Sync	Video	Power Indicator	Power Consumption
Normal operation	Active	Active	Active	White	39 W (maximum)** 13 W (typical,without USB load)
Active-off mode	Inactive	Inactive	Blanked	White (Glowing)	Less than 0.3 W
Switch off	-	-	-	Off	Less than 0.3 W
	Energy Star Power Consumption			mption	
Pon			12.0 W		

42.3 kWh

P2217/P2217Wh

ETEC

VESA Modes	Horizontal Sync	Vertical Sync	Video	Power Indicator	Power Consumption
Normal operation	Active	Active	Active	White	45 W (maximum)** 18 W (typical, without USB load)
Active-off mode	Inactive	Inactive	Blanked	White (Glowing)	Less than 0.3 W
Switch off	-	-	-	Off	Less than 0.3 W
Energy Star				Power Consu	mption
P _{on}			15.2 W		
E _{tec}			48.5 kWh		

** Maximum power consumption with max luminance.

This document is informational only and reflects laboratory performance. Your product may perform differently, depending on the software, components and peripherals you ordered and shall have no obligation to update such information. Accordingly, the customer should not rely upon this information in making decisions about electrical tolerances or otherwise. No warranty as to accuracy or completeness is expressed or implied.

The OSD functions only in the normal operation mode. When any button is pressed in the Active-off mode, the following message will be displayed:

Dell P1917S/P1917SWh
No VGA signal from your device. Press any key on the keyboard or move the mouse to wake it up. If there is no display, press the monitor button again to select the correct input source.
Dell P2017H
No VGA signal from your device. Press any key on the keyboard or move the mouse to wake it up. If there is no display, press the monitor button again to select the correct input source.
Dell P2217/P2217Wh
 No VGA signal from your device. Press any key on the keyboard or move the mouse to wake it up. If there is no display, press the monitor button again to select the correct input source.

Activate the computer and the monitor to gain access to the OSD.



NOTE: This monitor is **ENERGY STAR**-compliant. **ENERGY STA**



 \mathbf{P}_{on} : Power consumption of on mode as defined in Energy Star 7.0 version.

E_{TEC}: Total energy consumption in kWh as defined in Energy Star 7.0 version.

Pin assignments

VGA connector



Pin Number	15-pin Side of the Connected Signal Cable
1	Video-Red
2	Video-Green
3	Video-Blue
4	GND
5	Self-test
6	GND-R
7	GND-G
8	GND-B
9	Computer 5V/3.3V
10	GND-sync
11 12	GND
12	DDC data
13	H-sync
14	V-sync
15	DDC clock



Pin Number	19-pin Side of the Connected Signal Cable	
1	T.M.D.S. Data 2+	
2	T.M.D.S. Data 2 Shield	
3	T.M.D.S. Data 2-	
4	T.M.D.S. Data 1+	
5	T.M.D.S. Data 1 Shield	
6	T.M.D.S. Data 1 -	
7	T.M.D.S. Data 0+	
8	T.M.D.S. Data 0 Shield	
9	T.M.D.S. Data 0-	
10	T.M.D.S. Clock +	
11	T.M.D.S. Clock Shield	
12	T.M.D.S. Clock -	
13	CEC	
14	Reserved (N.C. on device)	
15	SCL	
16	SDA	
17	DDC/CEC Ground	
18	+5V Power	
19	Hot Plug Detect	

DisplayPort connector



Pin Number	20-pin Side of the Connected Signal Cable
1	ML3 (n)
2	GND
3	ML3 (p)
4	ML2 (n)
5	GND
6	ML2 (p)
7	ML1 (n)
8	GND
9	ML1 (p)
10	MLO (n)
11	GND
12	MLO (p)
13	GND
14	GND
15	AUX (p)
16	GND
17	AUX (n)
18	Hot Plug Detect
19	Re-PWR
20	+3.3 V DP_PWR

Universal serial bus (USB) interface

This section gives you information about the USB ports that are available on the monitor.



NOTE: This monitor is Super-Speed USB 3.0 and High-Speed USB 2.0 compatible.

Transfer Speed	Data Rate	Power Consumption*
Super-speed	5 Gbps	4.5 W (Max, each port)
High speed	480 Mbps	4.5 W (Max, each port)
Full speed	12 Mbps	4.5 W (Max, each port)

Transfer Speed	Data Rate	Power Consumption*
High speed	480 Mbps	2.5 W (Max, each port)
Full speed	12 Mbps	2.5 W (Max, each port)
Low speed	1.5 Mbps	2.5 W (Max, each port)

USB 3.0 upstream connector



Pin Number	9-pin Side of the Connector
1	VCC
2	D-
3	D+
4	GND
5	SSTX-
6	SSTX+
7	GND
8	SSRX-
9	SSRX+

USB 3.0 downstream connector



Pin Number	9-pin Side of the Connector
1	VCC
2	D-
3	D+
4	GND
5	SSRX-
6	SSRX+
7	GND
8	SSTX-
9	SSTX+

USB 2.0 Downstream Connector



Pin Number	4-pin Side of the Connector
1	усс
2	DMD
3	DPD
4	GND

USB Ports

- 1 x USB 3.0 upstream bottom
- 2 x USB 2.0 downstream bottom
- 2 x USB 3.0 downstream side



NOTE: USB 2.0 functionality requires a USB 2.0-capable computer.

NOTE: The monitor's USB interface works only when the monitor is On or in the power save mode. If you turn Off the monitor and then turn it On, the attached peripherals may take a few seconds to resume normal functionality.

Plug and play capability

You can install the monitor in any Plug and Play-compatible system. The monitor automatically provides the computer system with its Extended Display Identification Data (EDID) using Display Data Channel (DDC) protocols so the system can configure itself and optimize the monitor settings. Most monitor installations are automatic, you can select different settings if desired. For more information about changing the monitor settings, see Operating your monitor.

LCD monitor quality and pixel policy

During the LCD Monitor manufacturing process, it is not uncommon for one or more pixels to become fixed in an unchanging state which are hard to see and do not affect the display quality or usability. For more information on Dell Monitor Quality and Pixel Policy, see Dell Support site at: www.dell.com/support/monitors.

Maintenance guidelines

Cleaning your monitor

WARNING: Before cleaning the monitor, unplug the monitor power cable from the electrical outlet.

∧ CAUTION: Read and follow the Safety instructions before cleaning the monitor.

For best practices, follow the instructions in the list below while unpacking, cleaning or handling your monitor:

- To clean your anti-static screen, lightly dampen a soft, clean cloth with water. If possible, use a special screen-cleaning tissue or solution suitable for the antistatic coating. Do not use benzene, thinner, ammonia, abrasive cleaners or compressed air.
- Use a lightly-dampened, warm cloth to clean the monitor. Avoid using detergent of any kind as some detergents leave a milky film on the monitor.
- If you notice white powder when you unpack your monitor, wipe it off with a cloth.
- Handle your monitor with care as a darker-colored monitor may get scratched and show white scuff marks more than a lighter-colored monitor.
- To help maintain the best image quality on your monitor, use a dynamically changing screen saver and turn off your monitor when not in use.

Setting up the monitor

Attaching the stand



NOTE: The stand is detached when the monitor is shipped from the factory.

U

NOTE: This is applicable for a monitor with a stand. When any other stand is bought, please refer to the respective stand setup guide for the set up instructions.

To attach the monitor stand.

- **1.** Follow the instructions on the flaps of carton to remove the stand from the top cushion that secures it.
- 2. Insert the stand base blocks fully into the stand slot.
- 3. Lift the screw handle and turn the screw clockwise.
- 4. After fully tightening the screw, fold the screw handle flat within the recess.



5. Lift the cover, as shown, to expose the VESA area for stand assembly.



- 6. Attach the stand assembly to the monitor.
 - **a.** Fit the two tabs on the upper part of the stand to the groove on the back of the monitor.
 - **b.** Press the stand down till it snaps into place.



7. Place the monitor upright.

NOTE: Lift the monitor carefully to prevent it from slipping or falling.

Connecting your monitor



MARNING: Before you perform any of the procedures in this section, follow the Safety instructions.

NOTE: Do not connect all cables to the computer at the same time. It is recommend to route the cables through the cable-management slot before you connect them to the monitor.

To connect your monitor to the computer:

- 1. Turn off your computer and disconnect the power cable.
- 2. Connect the VGA, HDMI or DP cable from your monitor to the computer.

Connecting the VGA cable



Connecting the HDMI cable (optional)



Connecting the DP cable



Connecting the USB 3.0 cable

After you have completed connecting the DP/HDMI cable, follow the procedures below to connect the USB 3.0 cable to the computer and complete your monitor setup:

- **1.** Connect the upstream USB 3.0 port (cable supplied) to an appropriate USB 3.0 port on your computer. (See Bottom View for details.)
- 2. Connect the USB 3.0 peripherals to the downstream USB 3.0 ports on the monitor.
- 3. Plug the power cables for your computer and monitor into a nearby outlet.
- **4.** Turn on the monitor and the computer. If your monitor displays an image, installation is complete. If it does not display an image, see Universal serial bus (USB) specific problems.
- 5. Use the cable slot on the monitor stand to organize the cables.



Organizing cables

Use the cable-management slot to organize the cables connected to your monitor.



Disconnecting the monitor stand



NOTE: To prevent scratches on the LCD screen while removing the stand, ensure that the monitor is placed on a soft and clean surface.



NOTE: This is applicable for a monitor with a stand. When any other stand is bought, please refer to the respective stand setup guide for the set-up instructions.

To remove the stand:

- **1.** Place the monitor on a soft cloth or cushion.
- 2. Press and hold the stand release button.
- **3.** Lift the stand up and away from the monitor.



Wall mounting (optional)



(Screw dimension: M4 x 10 mm).

Refer to the instructions that come with the VESA-compatible wall mounting kit.

- 1. Place the monitor panel on a soft cloth or cushion on a stable, flat table.
- 2. Remove the stand.
- **3.** Use a screwdriver to remove the four screws securing the plastic cover.
- 4. Attach the mounting bracket from the wall mounting kit to the monitor.
- **5.** Mount the monitor on the wall by following the instructions that comes with the wall mounting kit.

NOTE: For use only with UL or CSA or GS-listed wall mount bracket with minimum weight/load bearing capacity of 12.00 kg

Operating your monitor

Power on the monitor

Press the **U** button to turn on the monitor.



Using the front panel controls

Use the control buttons on the front of the monitor to adjust the image being displayed.



The following table describes the front panel buttons:

	Front Panel Button	Description
1	8	Use this button to choose from a list of preset modes.
	Shortcut key/Preset Modes	
2	Shortcut key/Input source	Use the input source menu to select between the different video signals that may be connected to your monitor.
3	Menu	Use the menu button to launch the on-screen display (OSD) and select the OSD menu. See Accessing the OSD menu.
4	Exit	Use this button to go back to the main menu or exit the OSD main menu.


Use the power button to turn the monitor on and off.

Solid white light indicates the monitor is turned on. Blinking white light indicates it is in powersave mode.

OSD controls

Use the buttons on the front of the monitor to adjust the image settings.



	Front Panel Button	Description
1	Up	Use the up button to increase values or move up in a menu.
2	Down	Use the down button to decrease values or move down in a menu.
3	ОК	Use the OK button to confirm your selection in a menu.
4	Back	Use the back button to go back to the previous menu.

Using the on-screen display (OSD) menu

Accessing the OSD menu

- **NOTE:** Any changes you make are automatically saved when you move to another menu, exit the OSD menu, or wait for the OSD menu to automatically close.
 - 1. Press the 🛅 button to display the OSD main menu.

Main menu for analog (VGA) input

Dell P	917S/P1917SWh	Energy Use		Dell P2017H		Energy Use	
٠ O	Brightness / Contrast			-O- Brightness	/ Contrast		
⇔	Auto Adjust	-ờị-	0	Auto Adjus	t	-ò-	0
⊕	Input Source			Input Source	ce		
61	Color			GL Color			
Ţ	Display			Display			
6	Energy	75%	75%	Energy		75%	75%
Ē	Menu			Menu			
*	Personalize			+ Personalize			
1H	Others			Others			
	Resolution: 1280x1024, 60Hz	_	_	C Resolution:	: 1600x900, 60Hz	_	
			$\land \lor \rightarrow \times$				$\land \lor \rightarrow \times$
		Dell P2217/P2217	Wh	Energy Use			
		-O- Brightne	ss / Contrast				
		🖨 🗛 Auto Adj	ust	-ờ-	O		
		Input Sor	псе				
		61 Color					
		Display					
		Energy		75%	75%		
		Menu					
		+ Personal	ize				
		1. Others					
		C Resolutio	m: 1680x1050, 60Hz				

- 2. Press the \triangle and \heartsuit buttons to move between the setting options. As you move from one icon to another, the option is highlighted.
- **3.** Press the \rightarrow button once to activate the highlighted option.
- 4. Press \Lambda and 💟 button to select the desired parameter.
- 5. Press \bigcirc and then use the \land and \checkmark buttons, according to the indicators on the menu, to make your changes.
- 6. Select the 🕤 button to return to the main menu.

lcon	Menu and Submenus	Description	
	Brightness/ Contrast	Use this menu to activate brightness/contrast adjustment	
	Brightness	Brightness adjusts the luminance of the backlight. Press the → button to increase the brightness and press the → button to decrease the brightness (min. 0 / max. 100). NOTE: Manual adjustment of brightness is disabled when dynamic contrast is switched on.	
	Contrast	 Adjust the brightness first, and then adjust the contrast only if further adjustment is necessary. Press the → button to increase the contrast and press the → button to decrease the contrast (min. 0 / max. 100). The contrast function adjusts the degree of difference between darkness and lightness on the monitor screen. 	

t	Auto Adjust	Use this key to activate automatic setup and adjust menu.
•		National Control Beng bit National Control National Control
		Non-the intervention Non-the intervention Image: Second
		The following dialog appears on a black screen as the monitor self-adjusts to the current input:
		Auto Adjustment in Progress
		Auto adjustment allows the monitor to self-adjust to the incoming video signal. After using auto adjustment, you can further tune your monitor by using the pixel clock (coarse) and phase (fine) controls under display settings.
		NOTE : Auto adjust does not occur if you press the button while there are no active video input signals or attached cables.
		This option is only available when you are using the analog (VGA) connector.

	Input Source	Use the input source menu to select between the different video signals that may be connected to your monitor.
		Implicit Name Specificities Implicities Name Specificities
	VGA	Select VGA input when you are using the analog (VGA) connector. Push 🔁 to select the VGA input source.
	DP	Select DP input when you are using the DP connector. Push 🕑 to select the DP input source.
	HDMI	Select HDMI input when you are using the HDMI connector. Push 🗩 to select the HDMI input source.
	Auto Select	Select auto select to scan for available input signals.
	Reset Input Source	Select this option to restore default Input Source.
ØI	Color	<complex-block></complex-block>

Dueset Mariler	
Preset Modes	When you select preset modes, you can choose standard, comfortview, multimedia, movie, game, warm, cool, or custom color from the list.
	 Standard: Loads the monitor's default color settings. This is the default preset mode.
	 ComfortView: Decreases the level of blue light emitted from the screen to make viewing more comfortable for your eyes.
	 Multimedia: Loads color settings ideal for multimedia applications.
	 Movie: Loads color settings ideal for movies.
	 Game: Loads color settings ideal for most gaming applications.
	 Warm: Increases the color temperature. The screen appears warmer with a red/yellow tint.
	 Cool: Decreases the color temperature. The screen appears cooler with a blue tint.
	 Custom Color: Allows you to manually adjust the color settings.
	Press the \Lambda and 💟 buttons to adjust the three colors
	(R, G, B) values and create your own preset color mode.
	Def (Hick/Gh70e) Derg (M) Def (M) Def (M) Wert Ricks Wart Ricks Man Adjust Man Man Man Man
	Others Description Image: Statistic District Control of
	Def 2012/2012/sc Desire for Anth Adaptimes Chromer Sama Shake Anth Adaptimes Sama Shake Construction Sama Shake Anth Adaptimes Construction Anth Adaptimes Sama Shake Anth Adaptimes Sama Shake

Input Color Format	Allows you to set the video input mode to: • RGB: Select this option if your monitor is connected to a computer or DVD player using the HDMI cable. • YPbPr: Select this option if your DVD player supports only YPbPr output. • • • • • • • • • • • • • • • • • • •
Hue	This feature can shift the color of the video image to green or purple. This is used to adjust the desired flesh tone color. Use or v to adjust the hue from 0 to 100. Press or to increase the green shade of the video image. Press v to increase the purple shade of the video image. NOTE: Hue adjustment is available only when you select Movie or Game preset mode.
Saturation	This feature can adjust the color saturation of the video image. Use (a) or (b) to adjust the saturation from 0 to 100. Press (c) to increase the monochrome appearance of the video image. Press (c) to increase the colorful appearance of the video image. NOTE: Saturation adjustment is available only when you select movie or game preset mode.
Reset Color	Allows your monitor color settings to the factory settings.

Ţ	Display	<image/>
	Aspect Ratio	Adjusts the image ratio to wide 16:9, 4:3 or 5:4(for P2017H). Adjusts the image ratio to wide 16:10, 4:3 or 5:4(for P2217/P2217Wh).
	Horizontal Position	Use 🐼 or 父 the buttons to adjust image left and right. Minimum is 0 (-). Maximum is 100 (+).
	Vertical Position	Use the 🐼 or 文 buttons to adjust image up and down. Minimum is 0 (-). Maximum is 100 (+).
	Sharpness	This feature can make the image look sharper or softer. Use 🐼 or 文 to adjust the sharpness from 0 to 100.
	Pixel Clock	The phase and pixel clock adjustments allow you to adjust your monitor to your preference. Use or v buttons to adjust for best image quality. Minimum is 0 (-). Maximum is 100 (+).
	Phase	If satisfactory results are not obtained using the phase adjustment, use the pixel clock (coarse) adjustment and then use phase (fine), again. Minimum is 0 (-). Maximum is 100 (+).
	Dynamic Contrast	Allows you to increase the level of contrast to provide sharper and more detailed image quality.
		Press the 🕞 button to select the dynamic contrast on or off. NOTE: Dynamic contrast provides higher contrast if you select game or movie preset mode.
	Response Time	User can select between fast or normal. (for P1917S/ P1917SWh and P2017H only)
	Reset Display	Select this option to restore default display settings.

•	Energy	
	Power Button LED	Allows you to set the power LED indicator on during active or off during active to save energy.
	USB	Allows you to enable or disable USB function during monitor standby mode. NOTE: USB ON/OFF under standby mode is only available when USB upstream cable unplugged. This option will be
	Reset Energy	grey out when USB upstream cable plug in. Select this option to restore default Energy settings.

Menu	<text></text>
Language	Language options set the OSD display to one of the eight languages (English, Spanish, French, German, Brazilian Portuguese, Russian, Simplified Chinese, or Japanese).
Rotation	Rotates the OSD by 90 degrees counter-clockwise.
Transparency	Select this option to change the menu transparency by pressing the \bigstar and \checkmark buttons from 0 to 100.
Timer	OSD hold time: sets the length of time the OSD will remain active after the last time you pressed a button.
	Use \bigcirc or \bigcirc to adjust the slider in 1 second increments, from 5 to 60 seconds.
Lock	Controls user access to adjustments. When lock is selected, no user adjustments are allowed. All buttons are locked.
	NOTE: When the OSD is locked, pressing the menu key takes you directly to the OSD settings menu, with 'OSD Lock' pre-selected on entry. Press and hold skey for 6 seconds to unlock and allow user access to all applicable settings.
Reset Menu	Reset all OSD settings to the factory preset values.

*	Personalize	
	Shortcut Key 1	User can select one of the following: preset modes, brightness/contrast, auto adjust, input source, aspect ratio(option),rotation to set the shortcut key 1.
	Shortcut Key 2	User can select one of the following: preset modes, brightness/contrast, auto adjust, input source, aspect ratio(option),rotation to set the shortcut key 2.
	Reset Personalization	Allows you to restore shortcut key to the default setting.
1111	Others	



NOTE: Your monitor has a built-in feature to automatically calibrate the brightness to compensate for LED aging.

OSD warning messages

When the **Dynamic Contrast** feature is enabled (in these preset modes: **Game** or **Movie**), the manual brightness adjustment is disabled.



When the monitor does not support a particular resolution mode, the following message is displayed:





This means that the monitor cannot synchronize with the signal that it is receiving from the computer. See Monitor specifications for the Horizontal and Vertical frequency ranges addressable by this monitor. Recommended mode is 1280 x 1024 (for P1917S/P1917SWh) or 1600 x 900 (for P2017H) or 1680 x 1050 (for P2217/ P2217Wh).

Before the **DDC/CI** function is disabled, the following message is displayed:

Dell P1917S/P1917SWh		
The function of adjusting a be disabled.	display setting using	9 PC application will
Do you wish to disable DD	C/CI function?	
	No	
	Yes	
Dell P2017H		
The function of adjusting be disabled.		y PC application will
The function of adjusting		y PC application will
The function of adjusting be disabled.		PC application will



When the monitor enters the **Power Save Mode**, the following message appears:

Dell P1917S/P1917SWh
Entering Power Save Mode.
(
Dell P2017H
Entering Power Save Mode.
(
Dell P2217/P2217Wh
Entering Power Save Mode.
(⁽¹⁾)

If you press any button other than the power button, the following messages will appear depending on the selected input:





If VGA, HDMI, or DP cable is not connected, a floating dialog box as shown below appears. The monitor will enter Power Save Mode after 4 minutes if left at this state.

Dell P1917S/P1917SWh
D No VGA Cable
The display will go into Power Save Mode in 4 minutes.
www.dell.com/support/monitors
Dell P2017H
I No VGA Cable
The display will go into Power Save Mode in 4 minutes.
www.dell.com/support/monitors
Dell P2217/P2217Wh
I No VGA Cable
The display will go into Power Save Mode in 4 minutes.
www.dell.com/support/monitors
or
Dell P1917S/P1917SWh
O No HDMI Cable
The display will go into Power Save Mode in 4 minutes.
www.dell.com/support/monitors



Or
Dell P1917S/P1917SWh
📟 🕖 No DP Cable
The display will go into Power Save Mode in 4 minutes.
www.dell.com/support/monitors
Dell P2017H
🚥 🕢 No DP Cable
The display will go into Power Save Mode in 4 minutes.
www.dell.com/support/monitors
Dell P2217/P2217Wh
📟 🕖 No DP Cable
The display will go into Power Save Mode in 4 minutes.
www.dell.com/support/monitors

See Troubleshooting for more information.

Setting up your monitor

Setting the maximum resolution

To set the maximum resolution for the monitor:

In Windows® 8, and Windows® 8.1:

- **1.** For Windows 8 and Windows 8.1, select the Desktop tile to switch to classic desktop.
- 2. Right-click on the desktop and click Screen resolution.
- Click the dropdown list of the Screen Resolution and select 1280 x 1024 (for P1917S/P1917SWh) or 1600 x 900 (for P2017H) or 1680 x 1050 (for P2217/ P2217Wh).
- 4. Click OK.

In Windows® 10:

- 1. Right-click on the desktop and click **Display settings**.
- 2. Click Advanced display settings.
- **3.** Click the dropdown list of **Resolution** and select **1280 x 1024** (for P1917S/ P1917SWh) or **1600 x 900** (for P2017H) or **1680 x 1050** (for P2217/P2217Wh).
- 4. Click Apply.

If you do not see 1280 x 1024 (for P1917S/P1917SWh) or 1600 x 900 (for P2017H) or 1680 x 1050 (for P2217/P2217Wh) as an option, you may need to update your graphics driver. Depending on your computer, complete one of the following procedures:

If you have a Dell desktop or portable computer:

• Go to www.dell.com/support, enter your computer's Service Tag, and download the latest driver for your graphics card.

If you are using a non-Dell computer (portable or desktop):

- Go to the support site for your computer and download the latest graphic drivers.
- Go to your graphics card website and download the latest graphic drivers.

Using the Tilt, Swivel, and Vertical Extension

NOTE: This is applicable for a monitor with a stand. When any other stand is bought, please refer to the respective stand setup guide for set up instructions.

Tilt, Swivel

With the stand attached to the monitor, you can tilt and swivel the monitor for the most comfortable viewing angle.



NOTE: The stand is detached when the monitor is shipped from the factory.

Vertical Extension



NOTE: The stand extends vertically up to 130 mm. The figure below illustrates how to extend the stand vertically.



Rotating the Monitor

Before you rotate the monitor, your monitor should be fully vertically extended (Vertical Extension) and fully tilted up to avoid hitting the bottom edge of the monitor.



NOTE: To use the Display Rotation function (Landscape versus Portrait view) with your Dell computer, you require an updated graphics driver that is not included with this monitor. To download the graphics driver, go to www.dell. com/support and see the Download section for Video Drivers for latest driver updates.

NOTE: When in the Portrait View Mode, you may experience performance degradation in graphic-intensive applications (3D Gaming and etc.).

Troubleshooting

WARNING: Before you begin any of the procedures in this section, follow the Safety instructions.

Self-test

Your monitor provides a self-test feature that allows you to check if your monitor is functioning properly. If your monitor and computer are properly connected but the monitor screen remains dark, run the monitor self-test by performing the following steps:

- **1.** Turn off both your computer and the monitor.
- **2.** Disconnect all video cables from the monitor. This way, the computer doesn't have to be involved.
- 3. Turn on the monitor.

If the monitor is working correctly, it detects that there is no signal and one of the following message appears. While in self-test mode, the power LED remains white.

Dell P19175/P1917SWh
🐵 🕖 No VGA Cable
The display will go into Power Save Mode in 4 minutes.
www.dell.com/support/monitors
Dell P2017H
O No VGA Cable
The display will go into Power Save Mode in 4 minutes.
www.dell.com/support/monitors
Dell P2217/P2217Wh
€ No VGA Cable
The display will go into Power Save Mode in 4 minutes.
www.dell.com/support/monitors



The display will go into Power Save Mode in 4 minutes.

www.dell.com/support/monitors







NOTE: This box also appears during normal system operation, if the video cable is disconnected or damaged.

4. Turn off your monitor and reconnect the video cable; then turn on both your computer and the monitor.

If your monitor remains dark after you reconnect the cables, check your video controller and computer.

Built-in diagnostics

Your monitor has a built-in diagnostic tool that helps you determine if any screen abnormality you experience is an inherent problem with your monitor, or with your computer and video card.



NOTE: You can run the built-in diagnostics only when the video cable is unplugged and the monitor is in *self-test mode*.



To run the built-in diagnostics:

- 1. Ensure that the screen is clean (no dust particles on the surface of the screen).
- **2.** Unplug the video cable(s) from the back of the computer or monitor. The monitor then goes into the self-test mode.
- 3. Press and hold button 1 for 5 seconds. A gray screen appears.
- 4. Carefully inspect the screen for abnormalities.
- 5. Press button 1 on the front panel again. The color of the screen changes to red.
- 6. Inspect the display for any abnormalities.
- 7. Repeat steps 5 and 6 to inspect the display in green, blue, black, white and text screens.

The test is complete when the text screen appears. To exit, press button 1 again.

If you do not detect any screen abnormalities upon using the built-in diagnostic tool, the monitor is functioning properly. Check the video card and computer.

Common problems

The following table contains general information about common monitor problems you might encounter and the possible solutions:

Common Symptoms	Possible Solutions
No video/power LED off	 Ensure that the video cable connecting the monitor and the computer is properly connected and secure. Verify that the power outlet is functioning properly using any other electrical equipment. Ensure that the correct input source is selected via the Input source menu.
No video/power LED on	 Increase brightness and contrast controls using the OSD. Perform monitor self-test feature check. Check for bent or broken pins in the video cable connector. Run the built-in diagnostics. Ensure that the correct input source is selected via the Input source menu.
Poor focus	 Eliminate video extension cables. Reset the monitor to Factory Settings (Factory Reset). Change the video resolution to the correct aspect ratio.
Shaky/jittery video	 Reset the monitor to Factory Settings (Factory Reset). Check environmental factors. Relocate the monitor and test in another room.
Missing pixels	 Cycle power on-off. Pixel that is permanently Off is a natural defect that can occur in LCD technology. For more information on Dell Monitor Quality and Pixel Policy, see Dell Support site at www.dell.com/support/monitors.
Stuck-on pixels	 Cycle power on-off. Pixel that is permanently off is a natural defect that can occur in LCD technology. For more information on Dell Monitor Quality and Pixel Policy, see Dell Support site at www.dell.com/support/monitors.
Brightness problems	 Reset the monitor to Factory Settings (Factory Reset). Adjust brightness & contrast controls via OSD.
Geometric distortion	 Reset the monitor to Factory Settings (Factory Reset). Adjust horizontal & vertical controls via OSD.
Horizontal/vertical lines	 Reset the monitor to Factory Settings (Factory Reset). Perform monitor self-test feature check and determine if these lines are also in self-test mode. Check for bent or broken pins in the video cable connector. Run the built-in diagnostics.

problemsis connected properly and is secure.Reset the monitor to Factory Settings (Factory Reset).Perform monitor self-test feature check to determine if the intermittent problem occurs in self-test mode.Missing colorPerform monitor self-test feature check.Ensure that the video cable connecting the monitor to the compu is connected properly and is secure.Check for bent or broken pins in the video cable connector.Wrong colorChange the Color Setting Mode in the Color Settings OSD to Graphics or Video depending on the application.Try different Preset Modes in Color settings OSD.Change the Input Color Format to RGB or YPbPr in the Color settings OSD.Image retention from a static image left on the monitor for a long period of timeVideo ghosting orChange the Response Time in the Display OSD to Fast or Normal		
 Contact Dell immediately. Intermittent problems Ensure that the video cable connecting the monitor to the compulis connected properly and is secure. Reset the monitor to Factory Settings (Factory Reset). Perform monitor self-test feature check to determine if the intermittent problem occurs in self-test mode. Missing color Perform monitor self-test feature check. Ensure that the video cable connecting the monitor to the compulis connected properly and is secure. Check for bent or broken pins in the video cable connector. Wrong color Change the Color Setting Mode in the Color Settings OSD to Graphics or Video depending on the application. Try different Preset Modes in Color settings OSD. Adjust R/G/B valin Custom Color in Color settings OSD. Change the Input Color Format to RGB or YPbPr in the Color settings OSD. Run the built-in diagnostics. Image retention from a static image left on the monitor for a long period of time Use the Power Management feature to turn off the monitor at all times when not in use (for more information, see Power managem modes). Alternatively, use a dynamically changing screensaver. 	5	Perform monitor self-test feature check to determine if the scrambled screen appears in self-test mode.Check for bent or broken pins in the video cable connector.
problemsis connected properly and is secure.Reset the monitor to Factory Settings (Factory Reset).Perform monitor self-test feature check to determine if the intermittent problem occurs in self-test mode.Missing colorPerform monitor self-test feature check.Ensure that the video cable connecting the monitor to the compu is connected properly and is secure.Check for bent or broken pins in the video cable connector.Wrong colorChange the Color Setting Mode in the Color Settings OSD to Graphics or Video depending on the application.Try different Preset Modes in Color settings OSD. Change the Input Color Format to RGB or YPbPr in the Color settings OSD.Image retention from a static image left on the monitor for a long period of timeUse the Power Management feature to turn off the monitor at all times when not in use (for more information, see Power managem modes).Video ghosting orChange the Response Time in the Display OSD to Fast or Normal	Safety related issues	
 Ensure that the video cable connecting the monitor to the computis connected properly and is secure. Check for bent or broken pins in the video cable connector. Wrong color Change the Color Setting Mode in the Color Settings OSD to Graphics or Video depending on the application. Try different Preset Modes in Color settings OSD. Adjust R/G/B valin Custom Color in Color settings OSD. Change the Input Color Format to RGB or YPbPr in the Color settings OSD. Run the built-in diagnostics. Image retention from a static image left on the monitor for a long period of time Alternatively, use a dynamically changing screensaver. Video ghosting or Change the Response Time in the Display OSD to Fast or Normal 		 Reset the monitor to Factory Settings (Factory Reset). Perform monitor self-test feature check to determine if the
Graphics or Video depending on the application. Try different Preset Modes in Color settings OSD. Adjust R/G/B valin Custom Color in Color settings OSD. Change the Input Color Format to RGB or YPbPr in the Color settings OSD. Run the built-in diagnostics. Image retention from a static image left on the monitor for a long period of time Video ghosting or Change the Response Time in the Display OSD to Fast or Normal	Missing color	• Ensure that the video cable connecting the monitor to the computer is connected properly and is secure.
 a static image left on the monitor for a long period of time Video ghosting or Change the Response Time in the Display OSD to Fast or Normal 	Wrong color	 Graphics or Video depending on the application. Try different Preset Modes in Color settings OSD. Adjust R/G/B value in Custom Color in Color settings OSD. Change the Input Color Format to RGB or YPbPr in the Color settings OSD.
	a static image left on the monitor for a	times when not in use (for more information, see Power management modes).
overshooting depending on your application and usage.	Video ghosting or overshooting	• Change the Response Time in the Display OSD to Fast or Normal depending on your application and usage.

Product-specific problems

Specific Symptoms	Possible Solutions
Screen image is too small	 Check the Aspect Ratio setting in the Display settings OSD. Reset the monitor to Factory Settings (Factory Reset).
Cannot adjust the monitor with the buttons on the side panel	 Turn off the monitor, unplug the power cord, plug it back, and then turn on the monitor. Check if the OSD menu is locked. If yes, press and hold the button above the power button for 6 seconds to unlock. (For more information, see Lock).
No input signal when user controls are pressed	 Check the signal source. Ensure the computer is not in standby or sleep mode by moving the mouse or pressing any key on the keyboard. Check if the video cable is plugged in properly. Disconnect and reconnect the video cable if necessary. Reset the computer or video player.
The picture does not fill the entire screen	 Due to different video formats (aspect ratio) of DVDs, the monitor may display in full screen. Run the built-in diagnostics.

Universal serial bus (USB) specific problems

Specific Symptoms	Possible Solutions
USB interface is not working	 Check that your monitor is turned On. Reconnect the upstream cable to your computer. Reconnect the USB peripherals (downstream connector). Switch Off and then turn On the monitor again. Reboot the computer. Some USB devices like external portable HDD require higher electric current; connect the device directly to the computer system.
Supre Speed USB 3.0 interface is slow	 Check that your computer is USB 3.0-capable Some computers have USB 3.0, USB 2.0, and USB 1.1 ports. Ensure that the correct USB port is used. Ensure that the correct USB port is used. Reconnect the upstream cable to your computer. Reconnect the USB peripherals (downstream connector). Reboot the computer.
Wireless USB peripherals stop working when a USB 3.0 device is plugged in	 Increase the distance between the USB 3.0 peripherals and the wireless USB receiver. Position your wireless USB receiver as close as possible to the wireless USB peripherals. Use a USB-extender cable to position the wireless USB receiver as far away as possible from the USB 3.0 port.

Appendix

WARNING: Safety Instructions



WARNING: Use of controls, adjustments, or procedures other than those specified in this documentation may result in exposure to shock, electrical hazards, and/or mechanical hazards.

For information on safety instructions, see the Safety, Environmental, and Regulatory Information (SFRI)

FCC notices (U.S. Only) and other regulatory information

For FCC notices and other regulatory information, see the regulatory compliance website located at www.dell.com/regulatory_compliance.

Contacting Dell

To contact Dell for sales, technical assistance, or customer service issues:

- 1. Go to www.dell.com/contactdell
- 2. Verify your country or region in the Choose a Country/Region drop-down list at the bottom of the page.
- **3.** Select the appropriate service or support link based on your requirement or choose the method of contacting Dell that is convenient for you. Dell provides several online and telephone-based support and service options. Availability varies by country and product, and some services may not be available in your area.



NOTE: If you do not have an active internet connection, you can find contact information on your purchase invoice, packing slip, bill, or Dell product catalog.